

RIDE THE ELEMENTS





GOXTREME® BLACKHAWK 4K

Up to 4K @30fps 2"/5cm LCD display 12.4MP sensor 60m waterproof case 170° wide view



GOXTREME® BLACK HAWK 4K

Display	2.0"/5cm
Waterproof case	Up to 60m waterproof
	12.4MP sensor
Image sensor	
Still image resolution	16M (4608x3456) (4:3) by interpolation, 14M (4254x3264) (4:3) by interpolation
	12M (4000x3000) (4:3), 8.3M (3840x2160) (16:9), 5M (2560x1920) (4:3), 3M (2048x1536) (4:3)
Video resolution	4K (3840x2160) 30fps (16:9)
	2.7K (2880x2160) 30fps (4:3), 2.7K (2704x2028) 30fps (4:3)
	2.7K (2704x1520) 30fps (16:9) (SuperView)
	2.5K (2560x1440) 60fps, 30fps (16:9)
	1440p (1920x1440) 60fps, 30fps (4:3)
	1080p (1920x1080) 120fps, 100fps (16:9)
	1080p (1920x1080) 60fps, 30fps (16:9) (SuperView)
	960p (1280x960) 120fps, 60fps, 30fps (4:3)
	720p (1280x720) 240fps, 200fps, 120fps, 60fps, 30fps (16:9)
	720p (1280x720) 120fps (SuperView)
Video with sound	Yes
Microphone	Build-in
External memory	Compatible with Micro SD cards up to 64GB, minimum U3 class10 (not included)
Externat memory	
Wide angle	170° fixed wide angle
	•
Wide angle	170° fixed wide angle
Wide angle Lens	170° fixed wide angle f=3mm
Wide angle Lens WiFi function	170° fixed wide angle f=3mm Yes
Wide angle Lens WiFi function Time lapse video	170° fixed wide angle f=3mm Yes Off / 1sec. / 2sec. / 5sec. / 10sec. / 30sec. / 60sec.
Wide angle Lens WiFi function Time lapse video Self Timer	170° fixed wide angle f=3mm Yes Off / 1sec. / 2sec. / 5sec. / 10sec. / 30sec. / 60sec. Off / 3sec. / 5sec. / 10sec. / 30sec. / 60 ec.
Wide angle Lens WiFi function Time lapse video Self Timer Burst Function	170° fixed wide angle f=3mm Yes Off / 1sec. / 2sec. / 5sec. / 10sec. / 30sec. / 60sec. Off / 3sec. / 5sec. / 10sec. / 30sec. / 60 ec. Off / 3 pictures per sec.
Wide angle Lens WiFi function Time lapse video Self Timer Burst Function Continous Shot	170° fixed wide angle f=3mm Yes Off / 1sec. / 2sec. / 5sec. / 10sec. / 30sec. / 60sec. Off / 3sec. / 5sec. / 10sec. / 30sec. / 60 ec. Off / 3 pictures per sec. Off / every 3sec. / 5sec. / 10sec. / 30sec. / 60sec.
Wide angle Lens WiFi function Time lapse video Self Timer Burst Function Continous Shot Compensation	170° fixed wide angle f=3mm Yes Off / 1sec. / 2sec. / 5sec. / 10sec. / 30sec. / 60sec. Off / 3sec. / 5sec. / 10sec. / 30sec. / 60 ec. Off / 3 pictures per sec. Off / every 3sec. / 5sec. / 10sec. / 30sec. / 60sec. -0.3 / 0.0 / +0.3 / +0.7 / +1.0 / +1.3 / +1.7 / +2.0
Wide angle Lens WiFi function Time lapse video Self Timer Burst Function Continous Shot Compensation ISO	170° fixed wide angle f=3mm Yes Off / 1sec. / 2sec. / 5sec. / 10sec. / 30sec. / 60sec. Off / 3sec. / 5sec. / 10sec. / 30sec. / 60 ec. Off / 3 pictures per sec. Off / every 3sec. / 5sec. / 10sec. / 30sec. / 60sec. -0.3 / 0.0 / +0.3 / +0.7 / +1.0 / +1.3 / +1.7 / +2.0 Auto, 100, 200, 400, 800, 1600
Wide angle Lens WiFi function Time lapse video Self Timer Burst Function Continous Shot Compensation ISO	170° fixed wide angle f=3mm Yes Off / 1sec. / 2sec. / 5sec. / 10sec. / 30sec. / 60sec. Off / 3sec. / 5sec. / 10sec. / 30sec. / 60 ec. Off / 3 pictures per sec. Off / every 3sec. / 5sec. / 10sec. / 30sec. / 60sec. -0.3 / 0.0 / +0.3 / +0.7 / +1.0 / +1.3 / +1.7 / +2.0 Auto, 100, 200, 400, 800, 1600 Auto / Cloudy / Daylight / Water / Outdoor /
Wide angle Lens WiFi function Time lapse video Self Timer Burst Function Continous Shot Compensation ISO White balance	170° fixed wide angle f=3mm Yes Off / 1sec. / 2sec. / 5sec. / 10sec. / 30sec. / 60sec. Off / 3sec. / 5sec. / 10sec. / 30sec. / 60 ec. Off / 3 pictures per sec. Off / every 3sec. / 5sec. / 10sec. / 30sec. / 60sec. -0.3 / 0.0 / +0.3 / +0.7 / +1.0 / +1.3 / +1.7 / +2.0 Auto, 100, 200, 400, 800, 1600 Auto / Cloudy / Daylight / Water / Outdoor / Incandescent / Flash / Fluorescent
Wide angle Lens WiFi function Time lapse video Self Timer Burst Function Continous Shot Compensation ISO White balance	 170° fixed wide angle f=3mm Yes Off / 1sec. / 2sec. / 5sec. / 10sec. / 30sec. / 60sec. Off / 3sec. / 5sec. / 10sec. / 30sec. / 60 ec. Off / 3 pictures per sec. Off / every 3sec. / 5sec. / 10sec. / 30sec. / 60sec. -0.3 / 0.0 / +0.3 / +0.7 / +1.0 / +1.3 / +1.7 / +2.0 Auto, 100, 200, 400, 800, 1600 Auto / Cloudy / Daylight / Water / Outdoor / Incandescent / Flash / Fluorescent Photo: JPEG, Video: H.264 MP4
Wide angle Lens WiFi function Time lapse video Self Timer Burst Function Continous Shot Compensation ISO White balance File format PC interface	 170° fixed wide angle f=3mm Yes Off / 1sec. / 2sec. / 5sec. / 10sec. / 30sec. / 60sec. Off / 3sec. / 5sec. / 10sec. / 30sec. / 60 ec. Off / 3 pictures per sec. Off / every 3sec. / 5sec. / 10sec. / 30sec. / 60sec. -0.3 / 0.0 / +0.3 / +0.7 / +1.0 / +1.3 / +1.7 / +2.0 Auto, 100, 200, 400, 800, 1600 Auto / Cloudy / Daylight / Water / Outdoor / Incandescent / Flash / Fluorescent Photo: JPEG, Video: H.264 MP4 USB 2.0
Wide angle Lens WiFi function Time lapse video Self Timer Burst Function Continous Shot Compensation ISO White balance File format PC interface HDMI out	170° fixed wide angle f=3mm Yes Off / 1sec. / 2sec. / 5sec. / 10sec. / 30sec. / 60sec. Off / 3sec. / 5sec. / 10sec. / 30sec. / 60 ec. Off / 3 pictures per sec. Off / every 3sec. / 5sec. / 10sec. / 30sec. / 60sec. -0.3 / 0.0 / +0.3 / +0.7 / +1.0 / +1.3 / +1.7 / +2.0 Auto, 100, 200, 400, 800, 1600 Auto / Cloudy / Daylight / Water / Outdoor / Incandescent / Flash / Fluorescent Photo: JPEG, Video: H.264 MP4 USB 2.0 Yes



Waterproof case Bike mount Helmet mounts Orientation arms Tripod adaptor Monopod adaptor Battery USB cable Manual



GOACTION APP

Download the app from the App Store or Google Play and connect the action cam to your iOS or Android device via WiFi.

You can control your action cam by your phone or tablet. You can also transfer images or videos to your device and share them with your friends.









1 - 3 - 5



easypix

LIFESTYLE ELECTRONICS



State 1.07 control banks and and an and state to the state descent and the state descent

1050MAH LITHIUM BATTERY Art. Nr. 01471 EAN 4260041685239